

Remote upgrade operation manual

Manual upgrade:


Role: Installer, Owner

Scene: The user confirms the upgrade

Function entry: Any interface


When there are devices under your account that can be upgraded, you will receive a software upgrade reminder when logging into SolisCloud. You can choose to upgrade immediately or schedule an upgrade to remotely upgrade the designated device.

Upgrade Now:




You can also upgrade through the upgrade button in the upper right corner of the inverter/battery detail page.


Inverter:



Battery:




Do not cut off the power supply to the device during the upgrade process. The entire upgrade process takes approximately 40 to 45 minutes.




Upgrade by Appointment :

You can choose to upgrade your device at the time you want.




No longer remind :

Upgrade pop-ups will no longer be pushed to you. If you want to Upgrade later, you can enter the inverter details page and select [Inverter Upgrade].



Read the disclaimer and agree.



***If you encounter any issues such as unsuccessful upgrades or other problems, please contact your local [after-sales](#).**